

OWNER'S MANUAL

FOLDING CART MODEL: SFC



IMPORTANT! IT IS ESSENTIAL THAT YOU READ THE INSTRUCTIONS IN THIS MANUAL BEFORE ASSEMBLING, OPERATING AND MAINTAINING THIS PRODUCT.

Thank you for choosing this Sherpa product. It is important that you read the entire manual to become familiar with this product before you begin to assemble and use it. This cart is designed for certain applications only. We strongly recommend that you do not modify or use this cart for any application other than that for which it was designed. Both functional and efficient, this cart folds easily for storage. Use it for gardening and transporting goods.

SAFE USE INSTRUCTIONS

- Always check for damaged or worn out parts before using the cart. Broken parts will affect the cart's operation. Replace or repair damaged or worn parts immediately.
- Always chock all four wheels when loading or unloading the wagon on an incline.
- Keep parts and screws out of the reach of children.
- Tighten screws and bolts periodically.
- Distribute load evenly in cart.
- This cart is designed to carry goods, **DO NOT** use it as personal transportation.
- **DO NOT** modify the cart in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the cart was designed.
- **DO NOT** operate if any part is damaged or broken.
- **DO NOT** use on steep inclines where tipping may occur.
- **DO NOT** allow children to use this cart. **IT IS NOT A TOY!**
- **DO USE** care when unfolding and folding. Be aware of finger placement as pinching can occur.
- **DO NOT** exceed the maximum load capacity of 150KG. This must be evenly distributed.
- **DO NOT** lift or carry product by towing handle. Use fabric carry straps only. **DO NOT** lift when loaded.

LIMITED WARRANTY

Except to the extent otherwise provided herein, Sherpa Tools warrants that the Folding Trolley Cart ("Product") is free of defects in workmanship and materials. This Warranty extends only to the original consumer purchaser of the product ("Buyer"), is enforceable for a period of one (1) year from the date of original purchase (the "Warranty Period"), and covers only defects in material or workmanship. This Limited Warranty does not cover conditions or malfunctions resulting from normal wear and tear or otherwise due to the normal aging of the Product, neglect, abuse, accident, modifications, alterations, or repairs attempted or made by any entity or individual other than Sherpa Tools. This Warranty does not cover any damage to the Product caused by the environment or other natural events. Claims for breach of this Warranty must be made within the Warranty Period and within 30 days after Buyer discovers the fault. Buyer's remedies with respect to this Warranty are limited to the repair or replacement of defective parts after Sherpa Tools inspection and verification of a covered defect. Any Product to be considered for repair or replacement must be returned by Buyer to a duly authorised Sherpa Tools retail store or service centre. Buyer assumes all risks and liability whatsoever resulting from the use of the Product. In no event shall Sherpa Tools, its members or affiliates, be liable for any direct, indirect, special, incidental or consequential damages, lost revenues or profits, loss of business, or loss of goodwill, resulting from a defect in, or use of, the Product even if Sherpa Tools has been advised of the possibility thereof.

TO THE EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES SET FORTH HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. AS PERMITTED BY APPLICABLE LAW, DO IT BEST SPECIFICALLY DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS.

The provisions of this Warranty and limitation of liability may not be modified in any respect except in writing signed by a duly authorised officer of Sherpa Tools.

UNFOLDING INSTRUCTIONS



- 1 Remove the cart from the shipping carton and stand cart upright on its wheels. Save the carton for storage.



- 2 Release the velcro straps and grasp each end bar and pull apart until almost fully extended.



- 3 Push down on the middle of the base to ensure cart is full extended.



- 4 Unclip handle to use. To extend handle; release locking lever, extend to preferred length, lock into position using locking lever.

FOLDING INSTRUCTIONS



- 1 Retract the handle to its shortest point & clip into the frame.



- 2 Gently pull tab in middle of base upwards until cart begins to fold.



- 3 Grasp each end bar and push together until the cart is fully folded and wheels are all in-line.



- 4 Secure with straps for convenient transport & storage.

CARRYING / TRANSPORTATION

Fig1



Fig2



- To lift, ensure cart is securely folded according to instructions. Lift using fabric carry straps (Fig1).
- **DO NOT** lift or carry the cart by the towing handle (Fig2).
- **DO NOT** lift when loaded.

Sherpa Tools Ltd.
SFC FOLDING CART

If you experience any problems with this product, please do not return to the store. Contact Sherpa Tools direct on our UK helpline.

UK Helpline: 01522 283 020
www.sherpatools.co.uk

Jul 2017